




### Konformitätserklärung

Hiermit erklärt die Invento Products & Services GmbH, dass sich dieses Modell (Art.Nr. 500802) einschließlich Controller in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet. Die Konformitätserklärung kann unter folgender Adresse gefunden werden: [www.inventodownload.com/conformity](http://www.inventodownload.com/conformity)



## Gebrauchsanleitung

Bitte lesen Sie die Gebrauchsanleitung vor dem erstmaligen Betrieb aufmerksam durch. Gebrauchsanleitung bitte sorgfältig aufbewahren.

### Inhalt



Hovercraft  
1x




Sender  
1x



Antenne  
1x





Propeller  
2x





Gebrauchsanleitung  
1x

## Produktbeschreibung

### Hovercraft



### Sender



1

## Vorbereitung

1. Drücken Sie den Verschluss in die angegebene Richtung und entnehmen Sie den Sender (Abb. 1)




Abb. 1

3. Lösen Sie die Schrauben an der Unterseite der Hovercraft-Halterung (Abb. 3)




Abb. 3

5. Schrauben Sie die Antenne in die vorgesehene Buchse am Sender (Abb. 5)




Abb. 5

7. Schalten Sie den Sender ein (ON/OFF-Schalter in ON-Position bringen). Die Power LED leuchtet auf (Abb. 7)





Abb. 7

8. Schalten Sie das Hovercraft aus (ON/OFF-Schalter in OFF-Position bringen).

Öffnen Sie die Ladeabdeckung am Sender, entnehmen Sie das Ladekabel und stecken Sie den Ladestecker in die Ladebuchse des Hovercraft (Abb. 8). Die rote Lade-LED wird aufleuchten (Abb. 9) und nach 12 Minuten wieder erlöschen. Das Hovercraft ist nun aufgeladen.




Abb. 8




Abb. 9

2. Öffnen Sie den Deckel und entnehmen Sie die Antenne (Abb. 2)




Abb. 2

4. Drehen Sie die Befestigungsschrauben gegen den Uhrzeigersinn (Abb. 4)




Abb. 4

6. Öffnen Sie das Batteriefach mit einem Kreuzschlitz-Schraubendreher und legen Sie 4 x AA Batterien in das Batteriefach ein. Anschließend den Deckel wieder auf das Batteriefach schrauben (Abb. 6)




Abb. 6

## Bedienung

Ziehen Sie die Teleskopantenne auf Maximum aus, um die beste Sendeleistung zu erreichen. Anschließend das Hovercraft einschalten (ON/OFF-Schalter in ON-Position bringen) und in das Wasser setzen.

1. Vorwärts-Taste drücken:  
Das Hovercraft fährt  
vorwärts (Abb. 10)




Abb. 10



2. Rückwärts-Taste drücken:  
Das Hovercraft fährt  
rückwärts (Abb. 11)





Abb. 11



3. Durch gleichzeitiges  
Drücken der Vorwärts-  
Taste sowie der Links-  
Taste fährt das Hovercraft  
vorwärts in eine Linkskurve  
(Abb. 12)





Abb. 12



4. Durch gleichzeitiges  
Drücken der Vorwärts-  
Taste der  
Rechts-Taste fährt das  
Hovercraft vorwärts in eine  
Rechtskurve (Abb. 13)





Abb. 13



5. Durch gleichzeitiges  
Drücken der Rückwärts-  
Taste sowie der Links-  
Taste fährt das  
Hovercraft rückwärts  
in eine Linkskurve (Abb. 14)





Abb. 14



6. Durch gleichzeitiges  
Drücken der Rückwärts-Taste  
sowie der Rechts-Taste  
fährt das  
Hovercraft rück-  
wärts in eine Rechtskurve  
(Abb. 15)





Abb. 15



## Wichtige Hinweise

7. Links-Taste drücken:  
Das Hovercraft dreht auf  
der Stelle nach links  
(Abb. 16)




Abb. 16



8. Rechts-Taste drücken:  
Das Hovercraft dreht auf  
der Stelle nach rechts  
(Abb. 17)




Abb. 17



## Warn- und Sicherheitshinweise – bitte aufbewahren

- ▶ Propeller stellen eine ständige Verletzungsgefahr dar. Vermeiden Sie unter allen Umständen eine Berührung solcher Teile.
- ▶ Bitte verwenden Sie keine unterschiedlichen Batteriearten und mischen Sie nicht neue und alte Batterien.
- ▶ Bitte verwenden Sie nur den empfohlenen Batterie-Typ.
- ▶ Leere Batterien bitte aus dem Fahrzeug entfernen.
- ▶ Batterien bitte nicht in offenes Feuer werfen - Explosionsgefahr!
- ▶ Bitte keinen Kurzschluss verursachen.
- ▶ Bitte beim Einlegen der Batterien auf richtige Polarität achten.
- ▶ Bitte Batterien aus dem Produkt entfernen, wenn das Produkt für längere Zeit nicht genutzt wird.
- ▶ Packung aufbewahren! Enthält wichtige Informationen.
- ▶ Niemals Batterien aufladen, die dafür nicht bestimmt sind.
- ▶ Akkus nur unter Aufsicht von Erwachsenen laden.
- ▶ Batterien entfernen, wenn der Artikel über einen längeren Zeitraum nicht benutzt wird.

**ACHTUNG!** Nicht für Kinder unter 3 Jahren geeignet, da Kleinteile verschluckt werden können. Erstickungsgefahr!




Vertrieb:

INVENTO GmbH · Klein Feldhus 1 · D-26180 Rastede - Germany · service@invento-hq.com · www.invento-hq.com  
US Distribution by: HQ KITES & DESIGNS U.S.A., INC. · sales@hq-kites-usa.com · www.hq-kites-usa.com



### Declaration of Conformity

Herewith Invento Products & Services GmbH declares that this model (Art.No. 500802) including remote control meets the basic requirements and any other relevant requirements of guideline 1999/5/EC. The original declaration of conformity can be requested on [www.inventodownload.com/conformity](http://www.inventodownload.com/conformity)



## Instruction Manual

Please read the operating instructions carefully before using.  
Please keep operating instructions in a safe place.

## Contents



Hovercraft  
1x




Transmitter  
1x



Antenna  
1x






Propeller  
2x





Operating instructions  
1x

## Part Details

### Hovercraft




### Transmitter




## Preparation


1. Push the LOCK towards the direction shown to release the transmitter (fig. 1)



3. Remove the screw on the Hovercraft base as illustrated (fig. 3)




5. Insert and tighten the antenna to the antenna hole on the transmitter as illustrated (fig. 5)



7. Move the ON/OFF switch on the remote controller to ON. The power LED lights up (fig. 7)

POWER  CHARGE





POWER LED  CHARGE




8. Move the ON/OFF switch on the Hovercraft to OFF. Open the charger cover on the remote controller and take out the charging cable.


Insert the charging plug into the charging socket on the Hovercraft (fig. 8). The red charge LED lights up (charging in process, fig. 9) and will extinguish after 12 minutes (charged).




2. Remove the cover and take out the antenna (fig. 2)



4. Turn the retaining screws anticlockwise (fig. 4)



6. Use a Phillips screwdriver to open the battery compartment cover. Insert 4 x AA batteries with the correct polarity and replace the battery compartment cover (fig. 6)



## Operation

Extend the transmitter's antenna for better signal reception.  
Then move the ON/OFF switch on the Hovercraft to ON and put it into the water.

1. Press forward button:

The Hovercraft will move forwards (fig. 10)





fig. 10



2. Press backward button:

The Hovercraft will move backwards (fig. 11)





fig. 11



3. Pressing the LEFT button

on the transmitter while the Hovercraft is running forward, the Hovercraft will make left turns (fig. 12)





fig. 12



4. Pressing the RIGHT button

on the transmitter while the Hovercraft is running forward, the Hovercraft will make right turns (fig. 13)





fig. 13



5. Pressing the LEFT button

on the transmitter while the Hovercraft is running backward, the Hovercraft will make left turns (fig. 14)





fig. 14



6. Pressing the RIGHT button

on the transmitter while the Hovercraft is running backward, the Hovercraft will make right turns (fig. 15)





fig. 15  
Right



## Operation

7. Press left button:

The Hovercraft turns on the spot to the left (fig. 16)




fig. 16



8. Press right button:

The Hovercraft turns on the spot to the right (fig. 17)




fig. 17



## Warnings and Cautions – keep after reading

- ▶ Propellers are a constant source of injury. Never touch moving parts.
- ▶ Different types of batteries or new and used batteries are not to be mixed.
- ▶ Only batteries of the same or equivalent type as recommended are to be used.
- ▶ Exhausted batteries should be removed from the product.
- ▶ Do not dispose of batteries in fire, or batteries will explode or leak.
- ▶ The supply terminals are not to be short-circuited.
- ▶ Batteries are to be inserted with the correct polarity.
- ▶ Rechargeable batteries are to be removed from the product before being charged (if removable).
- ▶ The packaging has to be kept since it contains important information.
- ▶ Non-rechargeable batteries are not to be recharged.
- ▶ Rechargeable batteries are only to be charged under adult supervision.
- ▶ Remove batteries if the product is not to be used for an extended period.

WARNING! Not suitable for children under 3 years, because small parts could be swallowed. Choking hazard.



Distributed by:

INVENTO GmbH · Klein Feldhus 1 · D-26180 Rastede - Germany · [service@invento-hq.com](mailto:service@invento-hq.com) · [www.invento-hq.com](http://www.invento-hq.com)  
US Distribution by: HQ KITES & DESIGNS U.S.A., INC. · [sales@hq-kites-usa.com](mailto:sales@hq-kites-usa.com) · [www.hq-kites-usa.com](http://www.hq-kites-usa.com)